

## Outdoor Roller Blind Installation Guide

**Checklist:** You will need the following to perform the installation.

- Drill with hammer function for masonry/wood
- Screwdriver (Phillips)
- Measuring tape
- Marker (pencil)
- Ruler (recommended)
- Step ladder
- Spirit level (recommended)
- Hammer (not required but ideal)
- Vacuum to clean dust from drilling

### Hanging your blind:

#### **Step1.**

You need to determine if you are going to mount this into concrete or wood and purchase the necessary bolts for this.

#### **Step2.** *(Two persons recommended for this step)*

You will need to start by first mounting the brackets – Mount the one bracket with the rod (this being the controller side) and insert the control mechanism to it.



#### **Step3.**

Now we need to mount the Pin bracket – Hold the roller in the mounted bracket and then fit the pin bracket onto the other end of the roller pin (ensuring the pin is sufficiently secured). Position the Pin bracket in position but critical you ensure the blind is level otherwise the roller will not roll evenly. Now mark the position of the Pin bracket, remove the roller and then drill/screw the bracket in place.

#### **Step 4.**

Hook on the crank pole onto the control mechanism.



**Step 5.**

The roller has a chain at the bottom. The hooks can be mounted to the ground and the chain can be hooked to this. This will prevent the wind from lifting the blinds.



Blindsdirect.co.za